


Barrier Washer

Refer to Page 3 for Model Numbers



BAR18P_1300625

Parts

Table of Contents

Title	Page
Parts Ordering Information.....	2
Serial Plate Location	2
Model Identification	3
Electric Diagram For Models with Micro Control - Models Through 12/31/12.....	4
Electric Diagram For Models with Micro Control - Models Starting 1/1/13.....	6
Electric Diagram.....	8
Electrical Box - Electric and Steam Models (Drawing 1 of 3).....	10
Electrical Box - Electric and Steam Models (Drawing 2 of 3).....	12
Electrical Box - Electric and Steam Models (Drawing 3 of 3).....	14
Electrical Box - Gas Models.....	16
Gas Heating Diagram	18
Weighing Option with Micro Control.....	20
Frame Spare Parts (Drawing 1 of 2)	22
Frame Spare Parts (Drawing 2 of 2)	24
Motor and Pulley Spare Parts	26
Drum Spare Parts - Models Through May 2012	28
Drum Spare Parts - Models Starting June 2012	30
Drum Door Security	32
Basket Spare Parts - Models Through May 2012	34
Basket Spare Parts - Models Starting June 2012	36
Seal and Bearing Assembly	38
Water Circuit	40
Electric Heating Box.....	42
Gas Heating Spare Parts (Drawing 1 of 2)	44
Gas Heating Spare Parts (Drawing 2 of 2)	46
Steam Heating Spare Parts	48
Soap Dispenser	50
Parts Index.....	53

© Copyright 2014, Alliance Laundry Systems LLC

All rights reserved. No part of the contents of this book may be reproduced or transmitted in any form or by any means without the expressed written consent of the publisher.

Parts Ordering Information

If literature or replacement parts are required, contact the source from whom the machine was purchased or contact Alliance Laundry Systems at (920) 748-3950 for the name and address of the nearest authorized parts distributor.


For technical assistance, call either of the numbers listed below:

(920) 748-3121 Ripon, Wisconsin

+32 56 41 20 54 Wevelgem, Belgium

Serial Plate Location

When calling or writing about your product, be sure to mention model and serial numbers. Model and serial numbers are located on serial plate(s) as shown.




BAR18PA_1300625

Model Identification

Information in this manual is applicable to these barrier washer models:

HM270	UHM027D
HM330	UHM033D
HM490	UHM049D
HM670	UHM067D
IHM270	UHM270
IHM330	UHM330
IHM490	UHM490
IHM670	UHM670

Electric Diagram For Models with Micro Control - Models Through 12/31/12




BAR19P_1300625

Electric Diagram For Models with Micro Control - Models Through 12/31/12

REF	PART NO.	DESCRIPTION	COMMENTS
-		Gas Lighting Device	ALL
-		Emergency Stop	AU
-		Unbalance	Bal
-		Clean Side Opening Door Coil	BPP
-		Dirty Side Opening Door Coil	BPS
-		Auxiliary Contactor	CA
-		Electric Heating Contactor	CH
-		Relay Card	DANA1
-		Microprocessor Card	DANA2
-		Door Relay Card	DANA3
-		Liquid Soap Card	DANA4
-		Clean Side Detector	DP
-		Dirty Side Detector	DS
-		Hot Water	EC
-		Soft Water	ED
-		Cold Water	EF
-		Steam Valve	EVV
-		Fuse	F1, 2....
-		Javel Product	JAV; Bac 3
-		Wash Product	LAV; Bac 2
-		Motor 1	M1
-		Weighting Option Button	PES
-		Prewash Product	PRE; Bac 1
-		Safety Pressostat	PRS
-		Serial Port	PS
-		Rinsing Bac	RB; Bac 7
-		Cycle Relay	RC1/2
-		Door Safety Switch	SP1; Dirty side
-		Door Safety Switch	SP2; Clean side
-		Regulation Sensor	SR
-		Boiler Thermostat 1	Th C1
-		Boiler Thermostat 2	Th C2
-		Chimnet Thermostat	ThE
-		Gas Default Light	VDG
-		Frequency Variator	VF
-		Drain Valve	VID
-		Run Pilot Lamp	VM
-		Motor Ventilator 1	VM1

Electric Diagram For Models with Micro Control - Models Starting 1/1/13




BAR47P_1300625

Electric Diagram For Models with Micro Control - Models Starting 1/1/13

REF	PART NO.	DESCRIPTION	COMMENTS
-		Gas Lighting Device	ALL
-		Emergency Stop	AU
-		Unbalance	Bal
-		Clean Side Opening Door Coil	BPP
-		Dirty Side Opening Door Coil	BPS
-		Auxiliary Contactor	CA
-		Electric Heating Contactor	CH
-		Relay Card	DANA1
-		Microprocessor Card	DANA2
-		Door Relay Card	DANA3
-		Liquid Soap Card	DANA4
-		Clean Side Detector	DP
-		Dirty Side Detector	DS
-		Hot Water	EC
-		Soft Water	ED
-		Cold Water	EF
-		Steam Valve	EVV
-		Fuse	F1, 2....
-		Javel Product	JAV; Bac 3
-		Wash Product	LAV; Bac 2
-		Motor 1	M1
-		Weighting Option Button	PES
-		Prewash Product	PRE; Bac 1
-		Safety Pressostat	PRS
-		Serial Port	PS
-		Rinsing Bac	RB; Bac 7
-		Cycle Relay	RC1/2
-		Door Safety Switch	SP1; Dirty side
-		Door Safety Switch	SP2; Clean side
-		Regulation Sensor	SR
-		Boiler Thermostat 1	Th C1
-		Boiler Thermostat 2	Th C2
-		Chimnet Thermostat	ThE
-		Gas Default Light	VDG
-		Frequency Variator	VF
-		Drain Valve	VID
-		Run Pilot Lamp	VM
-		Motor Ventilator 1	VM1

Electric Diagram




BAR20P_1300625

Electric Diagram

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300613	Heater Element	270 models 6 required; 330 models 9 required; 490 models 12 required; 670 models 15 required; 3,000 Watt
2	1300548	Cylinder Motor	270 and 330 models; Models through May 2010
	1300651	Cylinder Motor	270 and 330 models; Models starting June 2010; 4 kW
	1300650	Cylinder Motor	490 and 670 models; 5.5 kW

Electrical Box - Electric and Steam Models (Drawing 1 of 3)




BAR23P_1300625

Electrical Box - Electric and Steam Models (Drawing 1 of 3)

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300962	Sensor Signal	
2	1300948	Sensor Converter	
3	1300963	Signal Converter	
4	1300021	Terminal Block	
	1300022	Terminal Block	
5	1300641P	Limit Connector Block	5 required
6	1300029	Ground Terminal	
7	1300071	Probe	
8	1300030	Folding Detector	2 required
9	1300047	Finger Guard Head Switch	270 and 330 models 1 required; 490 and 670 models 2 required
10	1300043	Position Switch Body	270 and 330 models 1 required; 490 and 670 models 2 required
11	1300964	Red Pilot	
12	1300853	Contactor	270 models 1 required; 330 and 490 models 2 required; 670 models 3 required
13	44018701P	Emergency Stop Kit	
	1300560P	Emergency Switch Kit	
14	1300944	Display	
15	1300945	Communication Cable Display	
16	1300955	Buzzer	
17	1300956	Recorder	
18	1300952	Frequency Variator	490 and 670 models
	1300953	Speed Variator	270 and 330 models
19	1300517	Ground Terminal Block	Steam models
	N/A	Ground Terminal	Electric models
20	1300556	Terminal Block	Steam models; 4 required
	1300954	Terminal Block	Electric models; 4 required
21	1300946	Transformer	
22	1300950	Card Extension Input/Output	
23	1300028	Fuse Holder	
24	1300957	Relay	2 required
	1300958	Relay Base	2 required
25	N/A	Relay	
26	1300957	Relay	
	1300958	Relay Base	
27	1300009	Fan Contactor	
28	1300057	Auxiliary Main Switch	670 models; Electric models
	1300965	Plastic Protection	670 models; Electric models
	1300966	Plastic Protection	670 models; Electric models
	1300056	Main Switch Handle	670 models; Electric models
	1300055	Main Switch	670 models
	1300054	Auxiliary Main Switch	270, 330 and 490 models; Electric models
	1300969	Plastic Protection	270, 330 and 490 models; Electric models
	1300967	Plastic Protection	270, 330 and 490 models; Electric models
	1300053	Main Switch Handle	270, 330 and 490 models; Electric models
	1300048P	Main Switch	270, 330 and 490 electric models; 270, 330, 490 and 670 steam models
	1300050P	Neutral Terminal	Steam models
	1300051	Main Switch Body	Steam models
	1300642P	Plastic Protection	Steam models
	1300049P	Main Switch Assembly	Steam models
29	1300968	Transformer	220 Volt
30	1300947	Battery	
31	1300959	Analog Switch	
32	1300961	Weight Piston	
33	1300960	Transformer	
34	1300951	PLC	

N/A = Part no longer available

Electrical Box - Electric and Steam Models (Drawing 2 of 3)




BAR24P_1300625

Electrical Box - Electric and Steam Models (Drawing 2 of 3)

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300972	Speed Variator	270 and 330 models
	1300971	Frequency Variator	490 and 670 models
2	1300648P	Safety Pressostat	
3	1300028	Fuse Holder	
4	1300021	Terminal Block	
5	1300641P	Limit Connector Block	2 required
6	1300021	Terminal Block	24 required
7	1300556	Terminal Block	10 required
8	1300029	Ground Terminal	
9	1300013	Heat Contactor	Electric models; 270 models 1 required; 330 and 490 models 2 required; 670 models 3 required
10	1300047	Finger Guard Head Switch	2 required
11	1300043	Position Switch Body	2 required
12	44018701P	Emergency Stop Kit	
	1300560P	Emergency Switch Kit	
13	1300052	Main Switch	270, 330 and 490 models
	1300053	Main Switch Handle	270, 330 and 490 models
	1300054	Auxiliary Main Switch	270, 330 and 490 models
	1300055	Main Switch	670 models
	1300056	Main Switch Handle	670 models
	1300057	Auxiliary Main Switch	670 models
	1300965	Plastic Protection	670 models
	1300967	Plastic Protection	270, 330 and 490 models
	1300969	Plastic Protection	270, 330 and 490 models
	1300970	Plastic Protection	670 models
14	1300649P	Temperature Probe	
15	1300647	Microprocessor Card	
16	1300040	Switch Head	
	1300042	Pushbutton Body	
17	1300643	Keyboard	
18	1300025	Heat Pilot Light	
	1300633	Lamp	
19	1300640	Flat Ribbon Cable	
20	1300639P	Flat Ribbon Cable	
21	1300637	Serial Port Cable	
22	1300638	Flat Ribbon Cable	
23	1300644	Liquid Soap Card	
24	1300646P	Relay Card	
25	1300645	Door Relay Card	
26	1300634P	Door Sensor	2 required

Electrical Box - Electric and Steam Models (Drawing 3 of 3)




BAR21P_1300625

Electrical Box - Electric and Steam Models (Drawing 3 of 3)

REF	PART NO.	DESCRIPTION	COMMENTS
	1300079P	Thermostat	
	1300025	Heat Pilot Light	
1	1300948	Sensor Converter	
2	1300022	Terminal Block	
3	1300021	Terminal Block	
4	1300029	Ground Terminal	
5	1300853	Contactor	270 models 1 required; 330 and 490 models 2 required; 670 models 3 required
6	1300071	Probe	
7	1300030	Folding Detector	2 required
8	1300047	Finger Guard Head Switch	2 required
9	1300043	Position Switch Body	2 required
10	44018701P	Emergency Stop Kit	
	1300560P	Emergency Switch Kit	
11	1300944	Display	
12	1300040	Switch Head	
	1300042	Pushbutton Body	
	1300559	Emergency Switch	5 required
	1300943	Emergency Switch	6 required
13	1300945	Communication Cable Display	
14	1300952	Frequency Variator	490 and 670 models
	1300953	Speed Variator	270 and 330 models
15	1300055	Main Switch	
	1300056	Main Switch Handle	
	1300059	Main Switch Extension	
	1300060	Door Lock	
16	1300597	3 Water Level Switch	
17	1300028	Fuse Holder	
18	1300011	Auxiliary Contactor	
19	1300009	Fan Contactor	
20	1300949	Card Entry Extension	
21	1300950	Card Extension Input/Output	
22	1300947	Battery	
23	1300946	Transformer	
24	1300951	PLC	

Electrical Box - Gas Models




BAR22P_1300625

Electrical Box - Gas Models

REF	PART NO.	DESCRIPTION	COMMENTS
	1300079P	Thermostat	
1	1300953	Speed Variator	270 and 330 models
	N/A	Speed Variator	490 and 670 models
2	1300028	Fuse Holder	
3	1300951	PLC	
4	1300950	Card Extension Input/Output	
5	1300949	Card Entry Extension	
6	1300948	Sensor Converter	
7	1300597	3 Water Level Switch	
8	1300947	Battery	
9	1300029	Ground Terminal	
10	1300071	Probe	
11	1300022	Terminal Block	
12	N/A	Pump Relay	
13	N/A	Circuit Breaker Pump	
14	N/A	Auxiliary Switch	
15	1300011	Auxiliary Contactor	
16	1300009	Fan Contactor	
17	1300055	Main Switch	
	1300056	Main Switch Handle	
	1300059	Main Switch Extension	
18	1300060	Door Lock	
19	1300946	Transformer	
20	1300006P	Igniter	
21	1300047	Finger Guard Head Switch	2 required
22	1300043	Position Switch Body	2 required
23	1300030	Folding Detector	2 required
24	N/A	Fireplace Safety Thermostat	
25	N/A	Water Safety Thermostat	
26	N/A	Boiler Safety Thermostat	
27	1300025	Heat Pilot Light	
28	1300040	Switch Head	
	1300042	Pushbutton Body	
	1300559	Emergency Switch	5 required
	1300943	Emergency Switch	6 required
29	1300945	Communication Cable Display	
30	1300944	Display	
31	44018701P	Emergency Stop Kit	
	1300560P	Emergency Switch Kit	
32	1300518	Gas Valve	
33	1300520P	Ignition Control	

N/A = Part no longer available

Gas Heating Diagram




BAR3P_1300625

Gas Heating Diagram

REF	PART NO.	DESCRIPTION	COMMENTS
-		Gas Lighting Device	ALL
-		Emergency Stop	AU
-		Gas Reset Button	BPG
-		Door Relay Card	DANA3
-		Pump Disjonctor	DIM
-		Gas Valve	EVG
-		Fuse	F1, 2....
-		Gas Pump	Pom
-		Pump Relay	RP
-		Gas Default Light	VDG
-		Pump Default Pump	VDP
-		Display XBTP	XBTP

Weighing Option with Micro Control




BAR4P_1300625

Weighing Option with Micro Control

REF	PART NO.	DESCRIPTION	COMMENTS
-		Emergency Stop	AU
-		Relay Card	DANA1
-		Relay Card	F1, 2....
-		Weighing Linen Indicator	IPB50
-		Weighing Option Button	PES
-		Cycle Relay	RC1/2
-		Auxiliary Relay	RS1
-		Temporized Relay	RTP1
-		Transformator 220AC/ 24 Continu	TR5
-		Electric Piston	VE

Frame Spare Parts (Drawing 1 of 2)




BAR5P_1300625

Frame Spare Parts (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300662	Clean Side Trim	Left
2	1300663	Upper Panel Bracket	2 required
3	1300668	Upper Spacer	670 models; 2 required
	1300669	Upper Spacer	490 models; 2 required
	1300670	Upper Spacer	330 models; 2 required
	1300671	Upper Spacer	270 models; 2 required
4	1300664	Equipment Mounting Plate	
5	1300653	Clean Side Trim	Right
6	1300652	Dirty Side Trim	Right
7	1300655	Unbalance Sensor Bracket	270 and 330 models 1 required; 490 and 670 models 2 required
8	1300665	Housing Reinforcing Bracket	2 required
9	1300654	Transport Bracket	
10	1300677	Housing	Right
11	1300660	Lower Panel Bracket	4 required
12	1300672	Base	670 models; 2 required
	1300673	Base	490 models; 2 required
	1300674	Base	330 models; 2 required
	1300675	Base	270 models; 2 required
13	1300656	Base Spacer	270 models; 2 required
	1300657	Base Spacer	330 models; 2 required
	1300658	Base Spacer	490 models; 2 required
	1300659	Base Spacer	670 models; 2 required
14	1300666	Body Seal	670 models; 2 required
	1300667P	Body Seal	All other models; 2 required
15	1300661	Dirty Side Trim	Left
16	1300676	Housing	Left

Frame Spare Parts (Drawing 2 of 2)




BAR6P_1300625

Frame Spare Parts (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	1300826	Section	2 required; Clean and dirty side
	1300839	Supply Dispenser Box Lid	
1	1300813	Cladding Panel	Right; Clean side
2	1300812	Top	
3	1300816	Vent Outlet	
4	1300814	Housing Top	Left
5	1300815	Cladding Panel	Left; Dirty side
6	1300817	Top Panel	670 models; Clean side
	1300818	Top Panel	490 models; Clean side
	1300819	Top Panel	330 models; Clean side
	1300820	Top Panel	270 models; Clean side
7	1300821	Top Panel	670 models; Dirty side
	1300822	Top Panel	490 models; Dirty side
	1300823	Top Panel	330 models; Dirty side
	1300824	Top Panel	270 models; Dirty side
8	1300827	Facade	670 models; Clean side
	1300828	Facade	490 models; Clean side
	1300829	Facade	330 models; Clean side
	1300830	Facade	270 models; Clean side
9	1300842	Cladding Panel	Left; Clean side
10	1300840	Housing Cover	Right
11	1300836	Supply Dispenser Latch	
12	1300837	Supply Dispenser Door	
13	1300835	Supply Dispenser Seal	
14	1300838	Supply Dispenser Box Assembly	
15	1300844	Panel	2 required; Left and right
16	1300843	Side Panel Brace	2 required
17	1300811	Steam Valve Plate	
18	1300841	Cladding Panel	Right; Dirty side
19	1300699	Facade	670 models; Dirty side
	1300831	Facade	490 models; Dirty side
	1300832	Facade	330 models; Dirty side
	1300833	Facade	270 models; Dirty side
20	1300845	Lower Panel	670 models; 2 required; Front and rear
	1300846	Lower Panel	490 models; 2 required; Front and rear
	1300847	Lower Panel	330 models; 2 required; Front and rear
	1300848	Lower Panel	270 models; 2 required; Front and rear
21	1300825	Facade Seal	4 required; Clean and dirty side

Motor and Pulley Spare Parts




BAR7P_1300625

Motor and Pulley Spare Parts

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300681	Motor Support Plate	
2	N/A	Drum Shaft Connecting Pin	
3	1300679	Door Position Detector Bracket	
4	1300678	Reflector	
5	1300682	Suspension Spring	670 models; 12 required
	1300683	Suspension Spring	All other models; 12 required
6	1300680P	Shock Absorber	4 required
7	N/A	Split Pin	4 required
8	1300688	Drum Pulley	
9	1300689	Drum Pulley Hub	
10	1300615	Belt	3 required
11	1300686	Motor Pulley Hub	490 and 670 models
	1300687	Motor Pulley Hub	270 and 330 models
12	1300684	Motor Pulley	490 and 670 models
	1300685	Motor Pulley	270 and 330 models

N/A = Part no longer available

Drum Spare Parts - Models Through May 2012




BAR8P_1300625

Drum Spare Parts - Models Through May 2012

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300719	Sidewall Counterweight	Left
2	1300718	Tank Sidewall	Left
3	1300717	Tank Sidewall Seal	2 required
4	1300713	Tank	670 models
	1300714	Tank	490 models
	1300715	Tank	330 models
	1300716	Tank	270 models
5	1300711	Tank Door	670 models; 2 required
	1300712	Tank Door	All other models; 2 required
6	1300709	Door Handle	670 models 6 required; All other models 4 required
7	1300708	Door Glass Seal	2 required
8	1300707	Door Glass	2 required
9	1300706	Door Glass Mount Bracket	4 required
10	1301020	Door Shock Absorber	670 models; 4 required
11	1300704	Suspension Spring Bracket	490 and 670 models; 2 required
	1300705	Suspension Spring Bracket	270 and 330 models; 2 required
12	1300703	Unbalance Sensor Bracket	670 models 2 required; All other models 1 required
13	1300655	Unbalance Sensor Bracket	670 models 2 required; All other models 1 required
14	1300691	Sidewall Counterweight	Right
15	1300690	Tank Sidewall	Right
16	1300694	Drum Door Prop	670 models; Clean Side; Left
	1300695	Drum Door Prop	670 models; Dirty Side; Left
	1300696	Drum Door Prop	670 models; Clean Side; Right
	1300697	Drum Door Prop	670 models; Dirty Side; Right
	1300692	Drum Door Prop	All other models; Dirty Side; Right
	1300693	Drum Door Prop	All other models; Clean Side; Right
17	1300701	Door Lock Bracket	670 models 4 required; All other models 2 required
18	1300610P	Door Lock	670 models 4 required; All other models 2 required
19	1300700	Door Lock Cover	670 models 4 required; All other models 2 required
20	1300698	Locking Bar Spring	670 models; 2 required
21	1300849	Drum Locking Bar	670 models; 2 required
22	1300702	Handle Catch	670 models 6 required; All other models 4 required
23	N/A	Safety Hook	2 required

N/A = Part no longer available

Drum Spare Parts - Models Starting June 2012




BAR45P_1300625

Drum Spare Parts - Models Starting June 2012

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300719	Sidewall Counterweight	Left
2	1300718	Tank Sidewall	Left
3	1300717	Tank Sidewall Seal	2 required
4	1300713	Tank	670 models
	1300714	Tank	490 models
	1300715	Tank	330 models
	1300716	Tank	270 models
5	1301131	Tank Door	670 models; 2 required
	1301132	Tank Door	All other models; 2 required
6	1301137	Door Glass Seal	2 required
7	1300707	Door Glass	2 required
8	1300706	Door Glass Mount Bracket	4 required
9	1301130	Door Shock Absorber	270, 330 and 490 models; 4 required
	1301020	Door Shock Absorber	670 models; 4 required
10	1300705	Suspension Spring Bracket	2 required
11	1301138	Unbalance Sensor Bracket	670 models 2 required; All other models 1 required
12	1300655	Unbalance Sensor Bracket	670 models 2 required; All other models 1 required
13	1300691	Sidewall Counterweight	Right
14	1300690	Tank Sidewall	Right
15	1300694	Drum Door Prop	670 models; Clean Side; Left
	1300696	Drum Door Prop	490 and 670 models; Clean Side; Right
	1301126	Drum Door Prop	270 and 330 models; Clean Side; Right
	1301127	Drum Door Prop	670 models; Dirty Side; Left
	1301128	Drum Door Prop	490 and 670 models; Dirty Side; Right
16	1301129	Door Lock Bracket	670 models 4 required; All other models 2 required
17	1300610P	Door Lock	670 models 4 required; All other models 2 required
18	1300698	Locking Bar Spring	670 models; 2 required
19	1300849	Drum Locking Bar	490 and 670 models; 2 required
20	1300695	Drum Door Prop	670 models; 2 required
	1301125	Door Handle	All other models; 2 required
21	1300610P	Door Lock	2 required; Models through 12/31/12
	1301148	Door Lock	2 required; Models starting 1/1/13

Drum Door Security




BAR31P_1300625

Drum Door Security

REF	PART NO.	DESCRIPTION	COMMENTS
1	1301149	Door Switch	2 required
2	1301144	Safety Microswitch Support Assembly	
3	1301136	Finger Guard	
4	1300939	Spring	

Basket Spare Parts - Models Through May 2012




BAR9P_1300625

Basket Spare Parts - Models Through May 2012

REF	PART NO.	DESCRIPTION	COMMENTS
	1300720	Beater	670 models; 8 required
	1300721	Beater	490 models; 4 required
	1300722	Beater	330 models; 4 required
	1300723	Beater	270 models; 4 required
1	1300739	Circlip	670 models 4 required; All other models 2 required
2	1300738	Door Closure Spring	670 models 4 required; All other models 2 required
3	1300861	Drum Handle	
4	1300626	Door Hook	670 models 2 required; All other models 1 required
5	1300850	Door Latch Spring	
6	1300735	Door Latch Yoke	670 models 2 required; All other models 1 required
7	1300736	Yoke Pin	670 models 2 required; All other models 1 required
8	1300734	Door Latch Yoke Spacer	670 models 4 required; All other models 2 required
9	1300732	Door Closure Joint	670 models 4 required; All other models 2 required
10	1300728	Upper Drum Door	670 models 2 required; All other models 1 required
11	1300729	Lower Drum Door	670 models 2 required; All other models 1 required
12	1300724	Drum Tie Rod	670 models; 4 required
	1300725	Drum Tie Rod	490 models; 4 required
	1300726	Drum Tie Rod	330 models; 4 required
	1300727	Drum Tie Rod	270 models; 4 required
13	1300731	Drum Spindle	
14	1300730	Drum Sidewall	2 required

Basket Spare Parts - Models Starting June 2012




BAR46P_1300625

Basket Spare Parts - Models Starting June 2012

REF	PART NO.	DESCRIPTION	COMMENTS
	1300720	Beater	670 models; 8 required
	1300721	Beater	490 models; 4 required
	1300722	Beater	330 models; 4 required
	1300723	Beater	270 models; 4 required
1	1301134	Drum Door Latch	670 models 4 required; All other models 2 required
2	1300739	Circlip	670 models 4 required; All other models 2 required
3	1301135	Spring	670 models 4 required; All other models 2 required
4	1301141	Upper Drum Door	670 models 2 required; All other models 1 required
5	1301142	Lower Drum Door	670 models 2 required; All other models 1 required
6	1301124P	Drum Knob	670 models 4 required; All other models 2 required
7	1300724	Drum Tie Rod	670 models; 4 required
	1300725	Drum Tie Rod	490 models; 4 required
	1300726	Drum Tie Rod	330 models; 4 required
	1300727	Drum Tie Rod	270 models; 4 required
8	1300731	Drum Spindle	Left
	1301140	Drum Spindle	Right
9	1301139	Drum Sidewall	2 required

Seal and Bearing Assembly




BAR10P_1300625

Seal and Bearing Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
1	1301143	Bearing Assembly	2 required
2	1300746	Bearing	2 required
3	1300744	Spiral Seal	4 required
4	1300743	Clip Retainer	2 required
5	1300741	Seal Flange	2 required
6	1300742	Sealing Ring	2 required
7	1300740	Counter Ring	2 required
8	1300745	Washer, Nut and Cone Kit	2 required

Water Circuit




BAR11P_1300625

Water Circuit

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300761	Connector Hose	Liquid products
2	1300755	Vent Hose	
3	1300756	Vent	
4	1300762	Inlet Valve Hose	670 models; 2 required
	1300763	Inlet Valve Hose	All other models; 2 required
5	1300188	Drain Tube	
6	1300764	Valve to Tank Hose	670 models; 2 required
	1300765	Valve to Tank Hose	All other models; 2 required
7	1300766	Connector	2 required
8	1300605P	Water Inlet Valve	670 models
	1300604P	Water Inlet Valve	All other models
9	1300757	Overflow Hose	
10	1300759	Drain Hose	
11	1300620	Drain Valve	
12	1300758	Tank to Drain Valve Hose	
13	1300760	Compression Tank	
14	1300748	Connector	T style
15	1300749	Connector	2 required
16	1300752	Solenoid Valve	2-Way
17	1300753	Solenoid Valve	3-Way
18	1300754	Valve to Tray Hose	
19	1300751	Bleach and Conditioner Product Tray	2 required
20	1300611	Product to Tank Tray Hose	
21	1300750	Prewash and Wash Product Tray	

Electric Heating Box




BAR12P_1300625

Electric Heating Box

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300767	Heat Tray Heating Element Spacer	670 models
	1300768	Heat Tray Heating Element Spacer	490 models
	1300769	Heat Tray Heating Element Spacer	330 models
	1300770	Heat Tray Heating Element Spacer	270 models
2	1300775	Heater Shield	670 models
	1300776	Heater Shield	490 models
	1300777	Heater Shield	330 models
	1300778	Heater Shield	270 models
3	1300613	Heater Element	270 models 6 required; 330 models 9 required; 490 models 12 required; 670 models 15 required
4	1300771	Heating Tray	670 models
	1300772	Heating Tray	490 models
	1300773	Heating Tray	330 models
	1300774	Heating Tray	270 models

Gas Heating Spare Parts (Drawing 1 of 2)




BAR13P_1300625

Gas Heating Spare Parts (Drawing 1 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
	1300627	Gas Valve	
1	1300789	Boiler Rear Plate	
2	1300785	Safety Thermostat Bracket	
3	1300788	Boiler Draft Hood	
4	1300787	Boiler Shell	
5	N/A	Union	
6	1300783	Boiler Thermostat Bracket	
7	1300781	Burner Orifice	When ordering, specify which type of gas
8	1300786	Boiler Front Plate	
9	N/A	Elbow	
10	N/A	Union	2 required
11	1300780	Union Fitting	
12	1300784	Boiler Door	
13	1300782	Inspection Plate	
14	1300779	Heating Tray	
15	1300793	Boiler Supply Hose	
16	1300792	Boiler Support Plate	
17	1300791	Boiler Return Hose	
18	N/A	Pipe	Copper; Gas valve to boiler
19	1300790	Boiler	Models through January 2012
20	1300171	Gas Valve Fitting	

N/A = Part no longer available

Gas Heating Spare Parts (Drawing 2 of 2)




BAR14P_1300625

Gas Heating Spare Parts (Drawing 2 of 2)

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300180	Reducing Bushing	
2	1300802	Pump Securing Bracket	
3	1300761	Connector Hose	Liquid products
4	1300794	Lint Filter Body	
5	1300799	Lint Filter and Flange Assembly	
6	1300798	Lint Filter Cap Seal	
7	1300797	Lint Filter Cap	
8	1300796	Tightening Ring	
9	1300795	Lint Filter Nut	
10	1300801	Pump Support Bracket	
11	1300800	Pipe	

Steam Heating Spare Parts




BAR15P_1300625

Steam Heating Spare Parts

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300803	Steam Valve Bracket	
2	1300809	Union Elbow	2 required
3	1300805	Steam Solenoid Valve	
4	1300806	Nipple	
5	1300807	Steam Filter	
6	1300810	Steam Diffuser	
7	1300808	Steam Heat Tray	
8	1300804	Steam Hose	

Soap Dispenser



BAR44P_1300625

Soap Dispenser

REF	PART NO.	DESCRIPTION	COMMENTS
1	1300754	Valve to Tray Hose	5 required
2	1300993	Collar	5 required
3	1301006	Water Injector	5 required
4	1301015	Liquid Soap Box	2 required
5	1300839	Supply Dispenser Box Lid	
6	1300998	Seal	
7	1301032	Liquid Soap Output	
8	1300994	Liquid Soap Collector	
9	1300904	Soap Collector Cork	
10	1301045	Soap Dispenser Panel	
11	1300990	Metallic Plate	2 required
12	1300989	Magnet	2 required
13	1300991	Door Handle	
14	1301047	Soap Dispenser Door Kit	
15	1301009	Siphon	2 required
16	1301019	Powder Soap Box	2 required
17	N/A	Nut	
18	1301010	Adapter	
19	1300188	Drain Tube	
20	1300992	Elbow	
21	1301014	Pipe	
22	1301018	Soap Dispenser	

N/A = Part no longer available

[illegible]

Parts Index

A

Adapter	1301010	51
Analog Switch	1300959	11
Auxiliary Contactor	1300011	15, 17
Auxiliary Main Switch	1300054	11, 13
	1300057	11, 13

B

Base	1300672	23
	1300673	23
	1300674	23
	1300675	23
Base Spacer	1300656	23
	1300657	23
	1300658	23
	1300659	23
Battery	1300947	11, 15, 17
Bearing	1300746	39
Bearing Assembly	1301143	39
Beater	1300720	35, 37
	1300721	35, 37
	1300722	35, 37
	1300723	35, 37
Belt	1300615	27
Bleach and Conditioner Product Tray	1300751	41
Body Seal	1300666	23
	1300667P	23
Boiler	1300790	45
Boiler Door	1300784	45
Boiler Draft Hood	1300788	45
Boiler Front Plate	1300786	45
Boiler Rear Plate	1300789	45
Boiler Return Hose	1300791	45
Boiler Shell	1300787	45
Boiler Supply Hose	1300793	45

Boiler Support Plate	1300792	45
Boiler Thermostat Bracket	1300783	45
Burner Orifice	1300781	45
Buzzer	1300955	11

C

Card Entry Extension	1300949	15, 17
Card Extension Input/Output	1300950	11, 15, 17
Circlip	1300739	35, 37
Cladding Panel	1300813	25
	1300815	25
	1300841	25
	1300842	25
Clean Side Trim	1300653	23
	1300662	23
Clip Retainer	1300743	39
Collar	1300993	51
Communication Cable Display	1300945	11, 15, 17
Compression Tank	1300760	41
Connector	1300748	41
	1300749	41
	1300766	41
Connector Hose	1300761	41, 47
Contacto	1300853	11, 15
Counter Ring	1300740	39
Cylinder Motor	1300548	9
	1300650	9
	1300651	9

D

Dirty Side Trim	1300652	23
	1300661	23
Display	1300944	11, 15, 17
Door Closure Joint	1300732	35
Door Closure Spring	1300738	35

N/A items do not appear in index.

Door Glass	
1300707	29, 31
Door Glass Mount Bracket	
1300706	29, 31
Door Glass Seal	
1300708	29
1301137	31
Door Handle	
1300709	29
1300991	51
1301125	31
Door Hook	
1300626	35
Door Latch Spring	
1300850	35
Door Latch Yoke	
1300735	35
Door Latch Yoke Spacer	
1300734	35
Door Lock	
1300060	15, 17
1300610P	29, 31
1301148	31
Door Lock Bracket	
1300701	29
1301129	31
Door Lock Cover	
1300700	29
Door Position Detector Bracket	
1300679	27
Door Relay Card	
1300645	13
Door Sensor	
1300634P	13
Door Shock Absorber	
1301020	29, 31
1301130	31
Door Switch	
1301149	33
Drain Hose	
1300759	41
Drain Tube	
1300188	41, 51
Drain Valve	
1300620	41
Drum Door Latch	
1301134	37
Drum Door Prop	
1300692	29
1300693	29
1300694	29, 31
1300695	29, 31
1300696	29, 31
1300697	29
1301126	31
1301127	31
1301128	31
Drum Handle	
1300861	35
Drum Knob	
1301124P	37
Drum Locking Bar	
1300849	29, 31

Drum Pulley	
1300688	27
Drum Pulley Hub	
1300689	27
Drum Sidewall	
1300730	35
1301139	37
Drum Spindle	
1300731	35, 37
1301140	37
Drum Tie Rod	
1300724	35, 37
1300725	35, 37
1300726	35, 37
1300727	35, 37

E

Elbow	
1300992	51
Emergency Stop Kit	
44018701P	11, 13, 15, 17
Emergency Switch	
1300559	15, 17
1300943	15, 17
Emergency Switch Kit	
1300560P	11, 13, 15, 17
Equipment Mounting Plate	
1300664	23

F

Facade	
1300699	25
1300827	25
1300828	25
1300829	25
1300830	25
1300831	25
1300832	25
1300833	25
Facade Seal	
1300825	25
Fan Contactor	
1300009	11, 15, 17
Finger Guard	
1301136	33
Finger Guard Head Switch	
1300047	11, 13, 15, 17
Flat Ribbon Cable	
1300638	13
1300639P	13
1300640	13
Folding Detector	
1300030	11, 15, 17
Frequency Variator	
1300952	11, 15
1300971	13
Fuse Holder	
1300028	11, 13, 15, 17

N/A items do not appear in index.

G

Gas Valve	
1300518	17
1300627	45
Gas Valve Fitting	
1300171	45
Ground Terminal	
1300029	11, 13, 15, 17
Ground Terminal Block	
1300517	11

H

Handle Catch	
1300702	29
Heat Contactor	
1300013	13
Heat Pilot Light	
1300025	13, 15, 17
Heat Tray Heating Element Spacer	
1300767	43
1300768	43
1300769	43
1300770	43
Heater Element	
1300613	9, 43
Heater Shield	
1300775	43
1300776	43
1300777	43
1300778	43
Heating Tray	
1300771	43
1300772	43
1300773	43
1300774	43
1300779	45
Housing	
1300676	23
1300677	23
Housing Cover	
1300840	25
Housing Reinforcing Bracket	
1300665	23
Housing Top	
1300814	25

I

Igniter	
1300006P	17
Ignition Control	
1300520P	17
Inlet Valve Hose	
1300762	41
1300763	41
Inspection Plate	
1300782	45

K

Keyboard	
1300643	13

L

Lamp	
1300633	13
Limit Connector Block	
1300641P	11, 13
Lint Filter and Flange Assembly	
1300799	47
Lint Filter Body	
1300794	47
Lint Filter Cap	
1300797	47
Lint Filter Cap Seal	
1300798	47
Lint Filter Nut	
1300795	47
Liquid Soap Box	
1301015	51
Liquid Soap Card	
1300644	13
Liquid Soap Collector	
1300994	51
Liquid Soap Output	
1301032	51
Locking Bar Spring	
1300698	29, 31
Lower Drum Door	
1300729	35
1301142	37
Lower Panel	
1300845	25
1300846	25
1300847	25
1300848	25
Lower Panel Bracket	
1300660	23

M

Magnet	
1300989	51
Main Switch	
1300048P	11
1300052	13
1300055	11, 13, 15, 17
Main Switch Assembly	
1300049P	11
Main Switch Body	
1300051	11
Main Switch Extension	
1300059	15, 17
Main Switch Handle	
1300053	11, 13
1300056	11, 13, 15, 17

N/A items do not appear in index.

Metallic Plate	
1300990	51
Microprocessor Card	
1300647	13
Motor Pulley	
1300684	27
1300685	27
Motor Pulley Hub	
1300686	27
1300687	27
Motor Support Plate	
1300681	27

N

Neutral Terminal	
1300050P	11
Nipple	
1300806	49

O

Overflow Hose	
1300757	41

P

Panel	
1300844	25
Pipe	
1300800	47
1301014	51
Plastic Protection	
1300642P	11
1300965	11, 13
1300966	11
1300967	11, 13
1300969	11, 13
1300970	13
PLC	
1300951	11, 15, 17
Position Switch Body	
1300043	11, 13, 15, 17
Powder Soap Box	
1301019	51
Prewash and Wash Product Tray	
1300750	41
Probe	
1300071	11, 15, 17
Product to Tank Tray Hose	
1300611	41
Pump Securing Bracket	
1300802	47
Pump Support Bracket	
1300801	47
Pushbutton Body	
1300042	13, 15, 17

R

Recorder	
1300956	11
Red Pilot	
1300964	11
Reducing Bushing	
1300180	47
Reflector	
1300678	27
Relay	
1300957	11
Relay Base	
1300958	11
Relay Card	
1300646P	13

S

Safety Microswitch Support Assembly	
1301144	33
Safety Pressostat	
1300648P	13
Safety Thermostat Bracket	
1300785	45
Seal	
1300998	51
Seal Flange	
1300741	39
Sealing Ring	
1300742	39
Section	
1300826	25
Sensor Converter	
1300948	11, 15, 17
Sensor Signal	
1300962	11
Serial Port Cable	
1300637	13
Shock Absorber	
1300680P	27
Side Panel Brace	
1300843	25
Sidewall Counterweight	
1300691	29, 31
1300719	29, 31
Signal Converter	
1300963	11
Siphon	
1301009	51
Soap Collector Cork	
1300904	51
Soap Dispenser	
1301018	51
Soap Dispenser Door Kit	
1301047	51
Soap Dispenser Panel	
1301045	51
Solenoid Valve	
1300752	41
1300753	41

N/A items do not appear in index.

Speed Variator	
1300953	11, 15, 17
1300972	13
Spiral Seal	
1300744	39
Spring	
1300939	33
1301135	37
Steam Diffuser	
1300810	49
Steam Filter	
1300807	49
Steam Heat Tray	
1300808	49
Steam Hose	
1300804	49
Steam Solenoid Valve	
1300805	49
Steam Valve Bracket	
1300803	49
Steam Valve Plate	
1300811	25
Supply Dispenser Box Assembly	
1300838	25
Supply Dispenser Box Lid	
1300839	25, 51
Supply Dispenser Door	
1300837	25
Supply Dispenser Latch	
1300836	25
Supply Dispenser Seal	
1300835	25
Suspension Spring	
1300682	27
1300683	27
Suspension Spring Bracket	
1300704	29
1300705	29, 31
Switch Head	
1300040	13, 15, 17
Switch, 3 Water Level	
1300597	15, 17

T

Tank	
1300713	29, 31
1300714	29, 31
1300715	29, 31
1300716	29, 31
Tank Door	
1300711	29
1300712	29
1301131	31
1301132	31
Tank Sidewall	
1300690	29, 31
1300718	29, 31
Tank Sidewall Seal	
1300717	29, 31
Tank to Drain Valve Hose	
1300758	41

Temperature Probe	
1300649P	13
Terminal Block	
1300021	11, 13, 15
1300022	11, 15, 17
1300556	11, 13
1300954	11
Thermostat	
1300079P	15, 17
Tightening Ring	
1300796	47
Top	
1300812	25
Top Panel	
1300817	25
1300818	25
1300819	25
1300820	25
1300822	25
1300823	25
1300824	25
Transformer	
1300946	11, 15, 17
1300960	11
1300968	11
Transport Bracket	
1300654	23

U

Unbalance Sensor Bracket	
1300655	23, 29, 31
1300703	29
1301138	31
Union Elbow	
1300809	49
Union Fitting	
1300780	45
Upper Drum Door	
1300728	35
1301141	37
Upper Panel Bracket	
1300663	23
1300670	23
Upper Spacer	
1300668	23
1300669	23
1300671	23

V

Valve to Tank Hose	
1300764	41
1300765	41
Valve to Tray Hose	
1300754	41, 51
Vent	
1300756	41
Vent Hose	
1300755	41
Vent Outlet	
1300816	25

N/A items do not appear in index.

W

Washer, Nut and Cone Kit	
1300745	39
Water Injector	
1301006	51
Water Inlet Valve	
1300604P	41
1300605P	41
Weight Piston	
1300961	11
Word	
1300821	25

Y

Yoke Pin	
1300736	35
