


Homestyle Frontload Washers

Refer to Page 3 for Model Numbers



FLW2406N_805862

Table of Contents

Title	Page
Parts Ordering Information.....	2
Serial Plate Location	2
Model Identification	3
Control Cabinet, Top and Controls	4
Graphic Panel, Control Support Panel and Controls	6
Control Panel and Control.....	8
Top and Hood Back Panel	10
Front Panel, Door Assembly and Door Seal	12
Dispenser Assembly	14
Mixing Valve, Fill Hose and Valve-to-Dispenser Hose	16
Outer Tub, Front and Clamp Ring	18
Inner Basket, Trunnion, Bearing Housing and Pulley	20
Motor and Belt.....	22
Drain Hose and Pump.....	24
Washer Base, Side Panels and Rear Panel	26
Junction Box and Power Cord	28
Junction Box	30
Special Tools	32
Washer Labels	34
Shipping Materials	36
Wire Ties, Clips and Lead-In Cord	38
Wire Harnesses and Wires	40
Parts Index.....	43

© Copyright 2015, Alliance Laundry Systems LLC

All rights reserved. No part of the contents of this book may be reproduced or transmitted in any form or by any means without the expressed written consent of the publisher.

Parts Ordering Information

If literature or replacement parts are required, contact the source from whom the machine was purchased or contact Alliance Laundry Systems at (920) 748-3950 for the name and address of the nearest authorized parts distributor.


For technical assistance, call either of the numbers listed below:

(920) 748-3121 Ripon, Wisconsin

+32 56 41 20 54 Wevelgem, Belgium

Serial Plate Location

When calling or writing about your product, be sure to mention model and serial numbers. Model and serial numbers are located on serial plate(s) as shown.



FLW2407N_805862


Model Identification

Information in this manual is applicable to these washer models:

AFBE9BSP303NN29	LFN50RSP113TW01	UFNE5BJP113TW01
AFBE9BSP303NW29	LFNE5BJP113TW01	UFNE5BJP113TW08
AFN50RSP113FW01	LFNE5BSP113FW01	YFNE5BJP113CW01
AFNE9BSP113FN01	LFNE5BSP113JW01	YFNE5RSP113CW01
AFNE9BSP303AN01	LFNE5BSP113TW01	ZFNE9BSP113CN01
AFNE9BSP303AW01	LFNE5BSP303AW01	ZFNE9BSP113CW01
AFNE9BSP303HN01	LFNE5BSP303AW12	ZFNE9BSP113FN01
AFNE9BSP303NN22	LFNE5BSP303ZW01	ZFNE9BSP113FW01
AFNE9BSP543ZN01	LFNE5BSP543ZW01	
BFNE6BJP113CW01	LFNE5RSP113FW01	
BFNE6BJP113TW01	LFNE5RSP113TW01	
FFNE5RSP303NW10	LFNE5RSP303NW22	

Control Cabinet, Top and Controls

Front Control Models




FLW1763P_805862

Control Cabinet, Top and Controls

REF	PART NO.	DESCRIPTION	COMMENTS
1	804684	Top Panel	Stainless steel
	804685WP	Top Panel	White
2	29651	Bolt	
3	804609	Terminal Block Panel	Models AFBE9BSP303NN29, AFBE9BSP303NW29, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP303NN22, AFNE9BSP543ZN01, LFNE5BSP113FW01, LFNE5BSP303AW01, LFNE5BSP303AW12, LFNE5BSP303ZW01, LFNE5BSP543ZW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
4	M400770	Snap Bushing	Models AFBE9BSP303NN29, AFBE9BSP303NW29, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP303NN22, AFNE9BSP543ZN01, LFNE5BSP113FW01, LFNE5BSP303AW01, LFNE5BSP303AW12, LFNE5BSP303ZW01, LFNE5BSP543ZW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
5	805633	Line Filter	Models AFBE9BSP303NN29, AFBE9BSP303NW29, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP303NN22, AFNE9BSP543ZN01, LFNE5BSP113FW01, LFNE5BSP303AW01, LFNE5BSP303AW12, LFNE5BSP303ZW01, LFNE5BSP543ZW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
6	804363	Control Shield	
7	503688	Screw	
8	804614	Rear Access Panel	
9	801788	Union	Models BFNE6BJP113CW01, BFNE6BJP113TW01, LFNE5BJP113TW01, UFNE5BJP113TW01, UFNE5BJP113TW08 and YFNE5BJP113CW01
10	801789	Connector	Models BFNE6BJP113CW01, BFNE6BJP113TW01, LFNE5BJP113TW01, UFNE5BJP113TW01, UFNE5BJP113TW08 and YFNE5BJP113CW01
11	804629W	Control Wrapper	Right; Models BFNE6BJP113CW01, BFNE6BJP113TW01, LFNE5BJP113TW01, UFNE5BJP113TW01, UFNE5BJP113TW08 and YFNE5BJP113CW01
	804630W	Control Wrapper	Right; White; All other models
	804630B	Control Wrapper	Right; Black; All other models
12	70030501	Expansion Clip	
13	39733	Screw	
14	803761	Top Panel Guide	
15	804613	Top Panel Brace Assembly	
16	804611	Control Bracket	
17	804425P	Control Assembly	Models AFBE9BSP303NN29, AFBE9BSP303NW29, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP303NN22, AFNE9BSP543ZN01, ZFNE9BSP113CN01, ZFNE9BSP113CW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
	804424P	Control Assembly	Models BFNE6BJP113CW01 and BFNE6BJP113TW01
	803912P	Control Assembly	All other models
18	804659W	Control Panel Assembly	White
	804660	Control Panel Assembly	Black
19	804490	Control Overlay	Model AFNE9BSP303AW01
	806107	Control Overlay	Model AFBE9BSP303NW29
	806108	Control Overlay	Model AFBE9BSP303NN29
	805549	Control Overlay	Models AFNE9BSP113FN01 and AFNE9BSP303AN01
	805564	Control Overlay	Models ZFNE9BSP113CN01 and ZFNE9BSP113FN01
	805569	Control Overlay	Models AFNE9BSP303HN01, AFNE9BSP303NN22 and AFNE9BSP543ZN01
	805695	Control Overlay	Models BFNE6BJP113TW01, LFNE5BJP113TW01, LFNE5BSP113FW01, LFNE5BSP113TW01, LFNE5BSP303AW01, LFNE5BSP303AW12, UFNE5BJP113TW01 and UFNE5BJP113TW08
	805696	Control Overlay	Models BFNE6BJP113CW01, LFNE5BSP113JW01, LFNE5BSP303ZW01, LFNE5BSP543ZW01 and YFNE5BJP113CW01
	805699	Control Overlay	Models ZFNE9BSP113CW01 and ZFNE9BSP113FW01
20	804627W	Control Wrapper	Left; White
	804627B	Control Wrapper	Left; Black
21	805345	Rear Wrapper Brace	
22	685847	Pop Rivet	

Models AFN50RSP113FW01 and LFN50RSP113TW01




Graphic Panel, Control Support Panel and Controls

REF	PART NO.	DESCRIPTION	COMMENTS
1	505808W	Top Cover	
2	501086	Screw	
3	35115	Temperature Switch	
4	800669	Temperature Switch Bracket	
5	801240	Cycle Switch	
6	801390	Cycle Switch Bracket	
7	504008WP	End Panel	Right
8	804474P	Control Assembly	
9	685837	Screw	
10	801388	Control Support Panel	
11	801356	Indicator Light	Green
12	805109W	Graphic Panel	Model AFN50RSP113FW01
	805714W	Graphic Panel	Model LFN50RSP113TW01
13	803168P	Knob Assembly	Model AFN50RSP113FW01
	512117W	Timer Knob Assembly	Model LFN50RSP113TW01
14	801435	Indicator Light Lens	
15	801434W	Push-to-Start Switch	
16	38424W	Rocker Switch	Extra rinse
17	803119P	Control Knob Assembly	Model AFN50RSP113FW01
	36701W	Knob Assembly	Model LFN50RSP113TW01
18	504009WP	End Panel	Left

Control Panel and Control

Models FFNE5RSP303NW10, LFNE5RSP113FW01, LFNE5RSP113TW01, LFNE5RSP303NW22 and YFNE5RSP113CW01




FLW1762P_805862

Control Panel and Control

REF	PART NO.	DESCRIPTION	COMMENTS
1	501086	Screw	
2	504009WP	End Panel	Left
3	505808W	Top Cover	
4	504008WP	End Panel	Right
5	804836	Control Support Panel	
6	804517	Control Assembly	Includes overlay; Models FFNE5RSP303NW10, LFNE5RSP113FW01, LFNE5RSP113TW01 and LFNE5RSP303NW22
	804789	Control Assembly	Includes overlay; Model YFNE5RSP113CW01
7	804492	Overlay	Models FFNE5RSP303NW10, LFNE5RSP113FW01, LFNE5RSP113TW01 and LFNE5RSP303NW22
	804493	Overlay	Model YFNE5RSP113CW01
8	805449	Graphic Panel	Model FFNE5RSP303NW10
	805448	Graphic Panel	Model YFNE5RSP113CW01
	805406	Graphic Panel	All other models

Top and Hood Back Panel

Rear Control Models




FLW1761P_805862

Top and Hood Back Panel

REF	PART NO.	DESCRIPTION	COMMENTS
1	804845	Hood Back Panel	Models AFN50RSP113FW01 and LFN50RSP113TW01
	804169	Hood Back Panel	All other models
2	500316	Warning Label	
	F8211201	Electrical Shock Label	
	505281	Disconnect Power Warning Label	
3	501086	Screw	
4	35358	Hold-Down Clip	
5	510146	Bracket	
6	70058501	Pop Rivet	
7	503661	Screw	
8	510029WP	Top Panel Kit	

Front Panel, Door Assembly and Door Seal




FLW1739P_805862

Front Panel, Door Assembly and Door Seal

REF	PART NO.	DESCRIPTION	COMMENTS
1	803710BP	Outer Door Bezel	Black; Models AFBE9BSP303NN29, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303HN01, AFNE9BSP303NN22, AFNE9BSP543ZN01, ZFNE9BSP113CN01 and ZFNE9BSP113FN01
	803710WP	Outer Door Bezel	White; All other models
2	800548	Screw	
3	804239	Door Glass Mounting Plate	
4	802695P	Door Glass	
5	685846	Nut	
6	804562	Inner Door Bezel	Glass filled polypropylene upgrade
	802331P	Inner Door Bezel Kit	Models AFBE9BSP303NN29, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303HN01, AFNE9BSP303NN22, AFNE9BSP543ZN01, ZFNE9BSP113CN01 and ZFNE9BSP113FN01
	802307P	Inner Door Bezel Kit	All other models
7	802803	Door Catch Assembly	
8	801993	Screw	
9	801019	Screw	
10	802934	Door Hinge	
11	23951	Nut	
12	802700	Glass Mounting Clip	7 required
13	56079	Panel Locator	
14	512921	Screw	Use with stainless steel panels
	39733	Screw	Use with painted panels
15	803920	Door Latch Assembly	
16	804784	Door Lock Drip Shield	Models AFN50RSP113FW01, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP543ZN01, LFNE5BSP113FW01, LFNE5BSP113JW01, LFNE5BSP303AW01, LFNE5BSP303AW12, LFNE5BSP303ZW01, LFNE5BSP543ZW01, LFNE5RSP113FW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
17	802283	Wire Clamp Ring	
18	802281	Hose Clamp	Seal to outer tub front
19	804428P	Door Seal	Black
20	802285	Extension Spring	
21	802206	Hinge Plate	
22	802288P	Front Panel	Stainless steel
	802277WP	Front Panel	White
23	503661	Screw	
24	36020	Nut	
25	801045	Screw	
26	804618	Access Panel Assembly	Stainless steel
	804617W	Access Panel Assembly	White
27	804083B	Door Assembly	Black; Includes items 1-12
	804083WP	Door Assembly	White; Includes items 1-12

Dispenser Assembly




FLW1772P_805862

Dispenser Assembly

REF	PART NO.	DESCRIPTION	COMMENTS
	804875	Foam Pad	
1	803843	Dispenser Plate	
2	801001	Screw	
3	804173	Hose Clamp	
4	803849	Dispenser Inlet Hose	
5	F200206	Hose Clamp	Models BFNE6BJP113CW01, BFNE6BJP113TW01, LFNE5BJP113TW01, UFNE5BJP113TW01, UFNE5BJP113TW08 and YFNE5BJP113CW01
6	801635	Tubing	Models BFNE6BJP113CW01, BFNE6BJP113TW01, LFNE5BJP113TW01, UFNE5BJP113TW01, UFNE5BJP113TW08 and YFNE5BJP113CW01
7	804717	Detergent Hose	
8	685725	Hose Clamp	
9	803698	Dispenser Assembly	
10	803667	Dispenser Drawer	
11	800548	Screw	
12	804227WP	Dispenser Handle	White
	804227B	Dispenser Handle	Black
13	803669	Compartment Cover	Models AFBE9BSP303NN29, AFBE9BSP303NW29, AFN50RSP113FW01, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP303NN22, AFNE9BSP543ZN01, ZFNE9BSP113CN01, ZFNE9BSP113CW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
	803670	Compartment Cover	All other models
14	805494	Dispenser Assembly	Models AFBE9BSP303NN29, AFBE9BSP303NW29, AFN50RSP113FW01, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP303NN22, AFNE9BSP543ZN01, ZFNE9BSP113CN01, ZFNE9BSP113CW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01; Includes items 9, 10 and 13
	805495	Dispenser Assembly	All other models; Includes items 9, 10 and 13

Mixing Valve, Fill Hose and Valve-to-Dispenser Hose




FLW1734P_805862

Mixing Valve, Fill Hose and Valve-to-Dispenser Hose

REF	PART NO.	DESCRIPTION	COMMENTS
	804783	Mixing Valve Shield	Models AFN50RSP113FW01, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP543ZN01, LFNE5BSP113FW01, LFNE5BSP113JW01, LFNE5BSP303AW01, LFNE5BSP303AW12, LFNE5BSP303ZW01, LFNE5BSP543ZW01, LFNE5RSP113FW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
1	804173	Hose Clamp	6 required
2	803849	Dispenser Inlet Hose	
3	803838	Mixing Valve	240 Volt; Models AFBE9BSP303NN29, AFBE9BSP303NW29, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP303NN22, AFNE9BSP543ZN01, FFNE5RSP303NW10, LFNE5BSP303AW01, LFNE5BSP303AW12, LFNE5BSP303ZW01, LFNE5BSP543ZW01 and LFNE5RSP303NW22
	803809	Mixing Valve	120 Volt; All other models
4	24122	Mixing Valve Screen	
5	20290	Washer	
6	F200116	Water Hose	Includes items 5, 7 and 8; Models BFNE6BJP113CW01, BFNE6BJP113TW01, FFNE5RSP303NW10, LFN50RSP113TW01, LFNE5BJP113TW01, LFNE5BSP113TW01, LFNE5RSP113TW01, LFNE5RSP303NW22, UFNE5BJP113TW01, UFNE5BJP113TW08, YFNE5BJP113CW01, YFNE5RSP113CW01, ZFNE9BSP113CN01 and ZFNE9BSP113CW01
7	803615	Washer	Filter screen
	802254	Washer	Flow restrictor; Water pressure reducer; Available for water pressure up to but not exceeding 120 psi
8	202800	Fill Hose	Models AFN50RSP113FW01, AFNE9BSP303AW01, AFNE9BSP303NN22, AFNE9BSP543ZN01, LFNE5BSP113FW01, LFNE5BSP113JW01, LFNE5BSP303AW01, LFNE5BSP303AW12, LFNE5BSP303ZW01, LFNE5BSP543ZW01 and LFNE5RSP113FW01
	202799	Fill Hose	Models AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303HN01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
	20617	Fill Hose	8 feet; Models BFNE6BJP113CW01, BFNE6BJP113TW01, FFNE5RSP303NW10, LFN50RSP113TW01, LFNE5BJP113TW01, LFNE5BSP113TW01, LFNE5RSP113TW01, LFNE5RSP303NW22, UFNE5BJP113TW01, UFNE5BJP113TW08, YFNE5BJP113CW01, YFNE5RSP113CW01, ZFNE9BSP113CN01 and ZFNE9BSP113CW01
	20618	Fill Hose	10 feet; Models BFNE6BJP113CW01, BFNE6BJP113TW01, FFNE5RSP303NW10, LFN50RSP113TW01, LFNE5BJP113TW01, LFNE5BSP113TW01, LFNE5RSP113TW01, LFNE5RSP303NW22, UFNE5BJP113TW01, UFNE5BJP113TW08, YFNE5BJP113CW01, YFNE5RSP113CW01, ZFNE9BSP113CN01 and ZFNE9BSP113CW01
	38349P	Fill Hose Kit	Models AFBE9BSP303NN29 and AFBE9BSP303NW29

Outer Tub, Front and Clamp Ring




FLW1765P_805862

Outer Tub, Front and Clamp Ring

REF	PART NO.	DESCRIPTION	COMMENTS
1	803415	Out-of-Balance Switch Assembly	
2	800461	Screw	
3	804458	Washer	
4	804457	Out-of-Balance Switch Bracket	
5	800452	Nut	
6	500049	Warning Label	
7	29175	Grommet	
8	803837	Pressure Bulb	
9	36985	Hose Clip	
10	804483	Pressure Sensor Tube Assembly	
11	803891	Hose Clamp	
12	803865	Outer Tub Assembly	Models AFBE9BSP303NN29 and AFBE9BSP303NW29
	803864	Outer Tub Assembly	All other models
13	803777	Shock Assembly	Must replace all four
14	803810	Counterweight	
15	803770	Tub Front	
16	806090	Heating Element	Includes thermistor; Models AFBE9BSP303NN29 and AFBE9BSP303NW29
17	F360202	Heating Element Plug	Models AFBE9BSP303NN29 and AFBE9BSP303NW29
18	803801	Tub Front Seal	
19	803802	Clamp Ring	
20	F430218	Nut	
21	M400081	Washer	
22	800462	Screw	
23	802596	Screw	
24	804467	Clothes Guard Deflector	
	805548	Clothes Guard Deflector	Heavy duty
25	803879	Tub Front Assembly	Includes items 15, 23, 24 and 26
26	802343	Nut	

Inner Basket, Trunnion, Bearing Housing and Pulley




FLW1736P_805862

Inner Basket, Trunnion, Bearing Housing and Pulley

REF	PART NO.	DESCRIPTION	COMMENTS
	27604P	Anti-Seize Compound	Pulley to inner basket shaft
1	804418	Nut	
2	804393	Balance Ring Assembly	
3	804382	Lifter	
4	805485	Inner Basket Assembly	Model LFNE5BSP303AW12
	804376	Inner Basket Assembly	All other models
5	804374P	Inner Basket Assembly	
6	804398	Screw	
7	804405	Trunnion Assembly	
8	804399	Screw	
9	800548	Screw	
10	800553	Hose Clip	
11	685847	Pop Rivet	
12	803974	Pulley Assembly	
13	800464	Washer	
14	685831	Screw	Left hand thread
15	M403958	Washer	
16	M400043	Screw	
17	M400081	Washer	
18	803684P	Bearing Housing Assembly	
19	800452	Nut	
20	803801	Tub Front Seal	
21	F430218	Nut	
22	800462	Screw	

Motor and Belt




FLW1770P_805862

Motor and Belt

REF	PART NO.	DESCRIPTION	COMMENTS
1	503661	Screw	
2	803949P	Inverter Control Assembly	
	804232P	Inverter Harness Assembly	
3	804878	Motor Control Shield	Models AFN50RSP113FW01, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP543ZN01, LFNE5BSP113FW01, LFNE5BSP113JW01, LFNE5BSP303AW01, LFNE5BSP303AW12, LFNE5BSP303ZW01, LFNE5BSP543ZW01, LFNE5RSP113FW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
	804792	Motor Control Shield	All other models
4	501524	Screw	
5	M400057	Screw	
6	02834	Washer	
7	M400080	Washer	
8	804985	Drive Belt	
9	803885P	Motor	
10	52549	Washer	
11	803861	Motor Rod	

Drain Hose and Pump




FLW1766P_805862

Drain Hose and Pump

REF	PART NO.	DESCRIPTION	COMMENTS
	805771	Pump-to-Drain Kit	120 Volt; Non-heat
	805769	Pump-to-Drain Kit	220 Volt; Heat
	805770	Pump-to-Drain Kit	220 Volt; Non-heat
1	33615	Drain Hose Sleeve	
2	33489	Standpipe Strap	
3	36014	Retainer Clip	
4	803976	Drain Hose	
5	32219	Strain Relief	
6	38732	Hose Stand	
7	F200204	Hose Clamp	
8	503661	Screw	
9	805561	Drain Pump Drip Shield	Models AFN50RSP113FW01, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP543ZN01, LFNE5BSP113FW01, LFNE5BSP113JW01, LFNE5BSP303AW01, LFNE5BSP303AW12, LFNE5BSP303ZW01, LFNE5BSP543ZW01, LFNE5RSP113FW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
10	803814	Drain Base Bracket	
11	802431	Screw	
12	802429P	O-Ring	
13	803815	Drain Pump Isolator	
14	805722P	Drain Pump Assembly	208-240 Volt; 60 Hertz; Includes items 8, 10-13 and 15-18; Models AFNE9BSP543ZN01 and LFNE5BSP543ZW01
	803921P	Drain Pump Assembly	120 Volt; 60 Hertz; Includes items 8, 10-13 and 15-18; Models BFNE6BJP113CW01, BFNE6BJP113TW01, LFN50RSP113TW01, LFNE5BJP113TW01, LFNE5BSP113TW01, LFNE5RSP113TW01, UFNE5BJP113TW01, UFNE5BJP113TW08, YFNE5BJP113CW01, YFNE5RSP113CW01, ZFNE9BSP113CN01 and ZFNE9BSP113CW01
	805724P	Drain Pump Assembly	100-127 Volt; 60 Hertz; Includes items 8, 10-13 and 15-18; Models AFN50RSP113FW01, AFNE9BSP113FN01, LFNE5BSP113FW01, LFNE5BSP113JW01, LFNE5RSP113FW01, ZFNE9BSP113FN01 and ZFNE9BSP113FW01
	803922	Drain Pump Assembly	220-240 Volt; 50 Hertz; Includes items 8, 10-13 and 15-18; All other models
15	802434P	Pump Housing Assembly	Includes items 16-18
16	802428	Pump Housing	
17	802427	Gasket	
18	802426P	Lid Assembly	Includes filter
19	803829	Tub-to-Pump Hose	
	27615P	Sealant	Tub-to-pump hose to outer tub

Washer Base, Side Panels and Rear Panel




FLW1721P_805862

Washer Base, Side Panels and Rear Panel

REF	PART NO.	DESCRIPTION	COMMENTS
	122P4P	Porcelain Touch-Up Paint	White
1	36226	Bumper Pad	
2	56079	Panel Locator	
3	512921	Screw	Use with stainless steel panels
	39733	Screw	Use with painted panels
4	802525P	Cabinet Side Panel	Left; Stainless steel
	800004WP	Cabinet Panel Kit	White; Left; Includes corner gusset with hardware
5	503661	Screw	
6	803790	Rear Panel	Fixed
7	510136	Top Hinge	Rear Control Models
8	803789	Rear Panel	Removable
9	803859	Shipping Plug	
10	803851	Shipping Plate	
11	803833	Gravity Drain Bracket	
	803828	Drain Hose Bracket	
12	802526P	Cabinet Side Panel	Right; Stainless steel
	800005W	Cabinet Side Panel	Right; White
13	34319	Leveling Leg	
14	501855	Rubber Foot	Use to prevent movement on smooth surface floor coverings; Install over two existing front rubber feet (item 15)
15	34318	Rubber Foot	
16	155P3	Anchor	Includes 4 rubber discs with adhesive backing
	802844P	Anchor Floor Mount Assembly	Includes 2 rubber discs with adhesive backing
17	21899	Nut	
18	803876	Base Assembly	
19	202470	Pressure Sensor	

Junction Box and Power Cord

Models AFBE9BSP303NN29, AFBE9BSP303NW29, AFN50RSP113FW01, AFNE9BSP113FN01, AFNE9BSP303AN01, AFNE9BSP303AW01, AFNE9BSP303HN01, AFNE9BSP303NN22, AFNE9BSP543ZN01, FFNE5RSP303NW10, LFNE5BSP113FW01, LFNE5BSP113JW01, LFNE5BSP303AW01, LFNE5BSP303AW12, LFNE5BSP303ZW01, LFNE5BSP543ZW01, LFNE5RSP113FW01, LFNE5RSP303NW22, ZFNE9BSP113FN01 and ZFNE9BSP113FW01




FLW1755P_805862

Junction Box and Power Cord

REF	PART NO.	DESCRIPTION	COMMENTS
1	803820	Junction Box Cover	
2	803832	Junction Box Seal	
3	39931	Power Cord Assembly	Models AFBE9BSP303NN29, AFBE9BSP303NW29, AFNE9BSP303AN01, AFNE9BSP303AW01, LFNE5BSP303AW01 and LFNE5BSP303AW12
	801450	Power Cord Assembly	Models AFNE9BSP303NN22, AFNE9BSP543ZN01, FFNE5RSP303NW10, LFNE5BSP303ZW01, LFNE5BSP543ZW01 and LFNE5RSP303NW22
	202624	Power Cord Assembly	Model LFNE5BSP113JW01
	805732	Power Cord Assembly	Model AFNE9BSP303HN01
	802012	Power Cord Assembly	All other models
4	39922	Cable Connection Box	
5	38384	Strain Relief	
6	804559	Junction Box	Upper; Model LFNE5BSP113JW01
	803818	Junction Box	Upper; All other models
7	805633	Line Filter	Models AFN50RSP113FW01, FFNE5RSP303NW10, LFNE5RSP113FW01 and LFNE5RSP303NW22
8	804396	Jumper Harness	Filter to terminal block; Models AFN50RSP113FW01, FFNE5RSP303NW10, LFNE5BSP113JW01, LFNE5BSP543ZW01, LFNE5RSP113FW01 and LFNE5RSP303NW22
9	503661	Screw	
10	803819	Junction Box	Lower
11	804805	Filter Jumper Harness	Filter to terminal block; All models except AFN50RSP113FW01, FFNE5RSP303NW10, LFNE5BSP113JW01, LFNE5RSP113FW01 and LFNE5RSP303NW22

Junction Box

Models BFNE6BJP113CW01, BFNE6BJP113TW01, LFNE5BJP113TW01, UFNE5BJP113TW01,
UFNE5BJP113TW08 and YFNE5BJP113CW01




FLW1756P_805862

Junction Box

REF	PART NO.	DESCRIPTION	COMMENTS
1	803820	Junction Box Cover	
2	803832	Junction Box Seal	
3	803827	Junction Box	Upper
4	M402542	Snap Bushing	
5	804528	Chemical Injection Control	
6	503661	Screw	
7	804561	Junction Box	Lower
8	M400149	Connector	
9	804799	Supply Injection Wire Harness Assembly	

Special Tools




FLW1733P_805862

Special Tools

REF	PART NO.	DESCRIPTION	COMMENTS
1	802336	Pulley Bolt Tightening Fixture	Use to install inner basket
2	392P4	Wrench	Use for adjusting leveling leg nuts

Washer Labels




FLW1722P_805862

Washer Labels

REF	PART NO.	DESCRIPTION	COMMENTS
1	803011	Notice Label	
2	802074	Oversudsing Label	English
	802838	Oversudsing Label	Spanish
3	802367	Warning Label	Reduce fire risk; Door locked
4	513371	Read Instructions Label	
5	505281	Disconnect Power Warning Label	English
	801706	Caution Label	Icon; Ground machine
	500316	Warning Label	English/French; Disconnect power
6	685928	Left Hand Thread Label	Text; Left hand thread
	804949	Left Hand Thread Label	Icon; Left hand thread
7	803260	Warning Label	Text; Disconnect power
	F8211201	Electrical Shock Label	Icon; Electric shock
8	500049	Warning Label	English
	500314	Warning Label	English/French
	F8211301	Pinched Fingers Label	Icon; Crush hazard

Shipping Materials




FLW1737P_805862

Shipping Materials

REF	PART NO.	DESCRIPTION	COMMENTS
	800462	Screw	2 required
	803858	Shipping Spacer	2 required
	803859	Shipping Plug	2 required
	800624	Washer	2 required
1	804488	Label	Shipping brace
2	M400014	Washer	4 required
3	M400043	Screw	4 required
4	804454	Shipping Brace	

Wire Ties, Clips and Lead-In Cord




FLW1771P_805862

Wire Ties, Clips and Lead-In Cord

REF	PART NO.	DESCRIPTION	COMMENTS
1	38663	Wire Tie	
2	55881	Harness Strap	
3	36985	Hose Clip	
4	03673	Nut	
5	03815	Washer	
6	20530	Screw	
7	38384	Strain Relief	
8	202777	Lead-In Cord	Models BFNE6BJP113CW01, BFNE6BJP113TW01, LFN50RSP113TW01, LFNE5BJP113TW01, LFNE5BSP113TW01, LFNE5RSP113TW01, UFNE5BJP113TW01, UFNE5BJP113TW08, YFNE5BJP113CW01, YFNE5RSP113CW01, ZFNE9BSP113CN01 and ZFNE9BSP113CW01

Wire Harnesses and Wires



FLW1757P_805862

Wire Harnesses and Wires

REF	PART NO.	DESCRIPTION	COMMENTS
	45001	18 Gauge Wire	Black; Order wire by foot and terminals as required
	45380	12 Gauge Wire	Orange; Order wire by foot and terminals as required
	804432	Pressure Sensor Harness	Rear control models
	804433	Pressure Sensor Harness	Front control models
1	806030	Rear Control Harness	Models AFN50RSP113FW01, FFNE5RSP303NW10, LFN50RSP113TW01, LFNE5RSP113FW01, LFNE5RSP113TW01, LFNE5RSP303NW22 and YFNE5RSP113CW01
	806031	Front Control Harness	All other models
2	806029	Motor Harness	
3	806028	Door Lock Harness Assembly	

NOTE: Individual wires are not available separately. Order complete harness, or order wire by the foot. When applying terminals to wires, it is recommended that the terminals be soldered to the wires.

This image shows a full page of blank white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page, providing a template for writing or drawing. There are no margins, text, or other markings present.

Parts Index

A

Access Pane Assemblyl	
804618	13
Access Panel Assembly	
804617W	13
Anchor	
155P3	27
Anchor Floor Mount Assembly	
802844P	27
Anti-Seize Compound	
27604P	21

B

Balance Ring Assembly	
804393	21
Base Assembly	
803876	27
Bearing Housing Assembly	
803684P	21
Bolt	
29651	5
Bracket	
510146	11
Bumper Pad	
36226	27

C

Cabinet Panel Kit	
800004WP	27
Cabinet Side Panel	
800005W	27
802525P	27
802526P	27
Cable Connection Box	
39922	29
Caution Label	
801706	35
Chemical Injection Control	
804528	31
Clamp Ring	
803802	19
Clothes Guard Deflector	
804467	19
805548	19
Compartment Cover	
803670	15
Connector	
M400149	31
801789	5
Control Assembly	
803912P	5
804424P	5
804425P	5
804474P	7
804517	9

804789	9
Control Bracket	
804611	5
Control Knob Assembly	
803119P	7
Control Overlay	
804490	5
805549	5
805564	5
805569	5
805695	5
805696	5
805699	5
806107	5
Control Panel Assembly	
804659W	5
804660	5
Control Shield	
804363	5
Control Support Panel	
801388	7
804836	9
Control Wrapper	
804627B	5
804627W	5
804629W	5
804630B	5
804630W	5
Counterweight	
803810	19
Cycle Switch	
801240	7
Cycle Switch Bracket	
801390	7

D

Detergent Hose	
804717	15
Disconnect Power Warning Label	
505281	11, 35
Dispenser Assembly	
803698	15
805494	15
805495	15
Dispenser Drawer	
803667	15
Dispenser Handle	
804227W	15
804227WP	15
Dispenser Inlet Hose	
803849	15, 17
Dispenser Plate	
803843	15
Door Assembly	
804083B	13
804083WP	13
Door Catch Assembly	
802803	13

N/A items do not appear in index.

Door Glass	
802695P	13
Door Glass Mounting Plate	
804239	13
Door Hinge	
802934	13
Door Latch Assembly	
803920	13
Door Lock Drip Shield	
804784	13
Door Lock Harness Assembly	
806028	41
Door Seal	
804428P	13
Drain Base Bracket	
803814	25
Drain Hose	
803976	25
Drain Hose Bracket	
803828	27
Drain Hose Sleeve	
33615	25
Drain Pump Assembly	
803921P	25
803922	25
805722P	25
805724P	25
Drain Pump Drip Shield	
805561	25
Drain Pump Isolator	
803815	25
Drive Belt	
804985	23

E

Electrical Shock Label	
F8211201	11, 35
End Panel	
504008W	9
504008WP	7
504009WP	7, 9
Expansion Clip	
70030501	5
Extension Spring	
802285	13

F

Fill Hose	
202799	17
202800	17
20617	17
20618	17
Fill Hose Kit	
38349P	17
Filter Jumper Harness	
804805	29
Foam Pad	
804875	15
Front Control Harness	
806031	41

N/A items do not appear in index.

Front Panel	
802277WP	13
802288P	13

G

Gasket	
802427	25
Glass Mounting Clip	
802700	13
Graphic Panel	
805109W	7
805406	9
805448	9
805449	9
805714W	7
Gravity Drain Bracket	
803833	27
Grommet	
29175	19

H

Harness Strap	
55881	39
Heating Element	
806090	19
Heating Element Plug	
F360202	19
Hinge Plate	
802206	13
Hold-Down Clip	
35358	11
Hood Back Panel	
804169	11
804845	11
Hose Clamp	
F200204	25
F200206	15
685725	15
802281	13
803891	19
804173	15, 17
Hose Clip	
36985	19, 39
800553	21
Hose Stand	
38732	25

I

Indicator Light	
801356	7
Indicator Light Lens	
801435	7
Inner Basket Assembly	
804374P	21
804376	21
805485	21
Inner Door Bezel	
804562	13

Inner Door Bezel Kit	
802307P	13
802331P	13
Insert	
685716	15
Inverter Control Assembly	
803949P	23
Inverter Harness Assembly	
804232P	23

J

Jumper Harness	
804396	29
Junction Box	
803818	29
803819	29
803827	31
804559	29
804561	31
Junction Box Cover	
803820	29, 31
Junction Box Seal	
803832	29, 31

K

Knob Assembly	
36701W	7
803168P	7

L

Label	
804488	37
Lead-In Cord	
202777	39
Left Hand Thread Label	
685928	35
804949	35
Leveling Leg	
34319	27
Lid Assembly	
802426P	25
Lifter	
804382	21
Line Filter	
805633	5, 29

M

Mixing Valve	
803809	17
803838	17
Mixing Valve Screen	
24122	17
Mixing Valve Shield	
804783	17

Motor	
803885P	23
Motor Control Shield	
804792	23
804878	23
Motor Harness	
806029	41
Motor Rod	
803861	23

N

Notice Label	
803011	35
Nut	
F430218	19, 21
03673	39
21899	27
23951	13
36020	13
685846	13
800452	19, 21
802343	19
804418	21

O

O-Ring	
802429P	25
Outer Door Bezel	
803710BP	13
803710WP	13
Outer Tub Assembly	
803864	19
803865	19
Out-of-Balance Switch Assembly	
803415	19
Out-of-Balance Switch Bracket	
804457	19
Overlay	
804492	9
804493	9
Oversuding Label	
802074	35
802838	35

P

Panel Locator	
56079	13, 27
Pinched Fingers Label	
F8211301	35
Pop Rivet	
685847	5, 21
70058501	11
Porcelain Touch-Up Paint	
122P4P	27
Power Cord Assembly	
202624	29
39931	29
801450	29

N/A items do not appear in index.

802012	29
805732	29
Pressure Bulb	
803837	19
Pressure Sensor	
202470	27
Pressure Sensor Harness	
804432	41
804433	41
Pressure Sensor Tube Assembly	
804483	19
Pulley Assembly	
803974	21
Pulley Bolt Tightening Fixture	
802336	33
Pump Housing	
802428	25
Pump Housing Assembly	
802434P	25
Pump-to-Drain Kit	
805769	25
805770	25
805771	25
Push-to-Start Switch	
801434W	7

R

Read Instructions Label	
513371	35
Rear Access Panel	
804614	5
Rear Control Harness	
806030	41
Rear Panel	
803789	27
803790	27
Rear Wrapper Brace	
805345	5
Retainer Clip	
36014	25
Rocker Switch	
38424W	7
Rubber Foot	
34318	27
501855	27

S

Screw	
M400043	21, 37
M400057	23
20530	39
39733	5, 13, 27
501086	7, 9, 11
501524	23
503661	11, 13, 23, 25, 27, 29, 31
503688	5
512921	13, 27
685831	21
685837	7
800461	19

800462	19, 21, 37
800548	13, 15, 21
801001	15
801019	13
801045	13
801993	13
802431	25
802596	19
804398	21
804399	21
Sealant	
27615P	25
Shipping Brace	
804454	37
Shipping Plate	
803851	27
Shipping Plug	
803859	27, 37
Shipping Spacer	
803858	37
Shock Assembly	
803777	19
Snap Bushing	
M400770	5
M402542	31
Standpipe Strap	
33489	25
Strain Relief	
32219	25
38384	29, 39
Supply Injection Wire Harness Assembly	
804799	31

T

Temperature Switch	
35115	7
Temperature Switch Bracket	
800669	7
Terminal Block Panel	
804609	5
Timer Knob Assembly	
512117W	7
Top Cover	
505808W	7, 9
Top Hinge	
510136	27
Top Panel	
804684	5
804685WP	5
Top Panel Brace Assembly	
804613	5
Top Panel Guide	
803761	5
Top Panel Kit	
510029WP	11
Trunnion Assembly	
804405	21
Tub Front	
803770	19
Tub Front Assembly	
803879	19

N/A items do not appear in index.

Tub Front Seal	
803801	19, 21
Tubing	
801635	15
Tub-to-Pump Hose	
803829	25

U

Union	
801788	5

W

Warning Label	
500049	19, 35
500314	35
500316	11, 35
802367	35
803260	35
Washer	
M400014	37
M400080	23
M400081	19, 21
M403958	21
02834	23
03815	39
20290	17
52549	23
800464	21
800624	37
802254	17
803615	17
804458	19
Water Hose	
F200116	17
Wire Clamp Ring	
802283	13
Wire Tie	
38663	39
Wire, 12 Gauge	
45380	41
Wire, 18 Gauge	
45001	41
Wrench	
392P4	33

[illegible]